TIMER BOX DIMENSIONS



11.75-inches high (13.94-inches including coin slot) x 7.31-inches wide x 3.82-inches deep